

How to use BLHeli Pass-Through for brushless Silverware quads

1. Prepare the board (this is not needed for our dedicated brushless boards).

I'll describe here how to prepare a BWhoop board, but the other boards should work smilarly. Be aware that relative fine soldering is needed - but don't be afraid, you only need to remove some stuff from the board. A hot air gun or second soldering iron is helpful, but not needed.

From:

<http://sirdomsen.diskstation.me/dokuwiki/> - Silverware Wiki

Permanent link:

<http://sirdomsen.diskstation.me/dokuwiki/doku.php?id=passthrough>

Last update: **2018/04/05 12:56**

