

# How to use BLHeli Pass-Through for brushless Silverware quads

## 1. Preparing the board(this is not needed for our dedicated brushless boards).

I'll describe here how to prepare a BWhoop board, but the other boards should work smilarly. Be aware that relative fine soldering is needed - but don't be afraid, you only need to remove some stuff from the board.

From:

<https://sirdomsen.diskstation.me/dokuwiki/> - **Silverware Wiki**

Permanent link:

<https://sirdomsen.diskstation.me/dokuwiki/doku.php?id=passthrough&rev=1522925672>

Last update: **2018/04/05 12:54**

