

SilF4ware Hardware Wiring

NRF24 Mini

Pin	Function
1	VCC (needs to be bridged with CE)
2	GND
3	CE (needs to be bridged with VCC)
4	CSN
5	SCK
6	MOSI
7	MISO
8	IRQ (not used)

Omnibus

See [SilF4ware/STM32F405 Omnibus/board_pinout.jpg](http://SilF4ware/STM32F405%20Omnibus/board_pinout.jpg)

Omnibus	NRF24 Mini
3.3V	VCC (bridge with CE)
GND	GND
	CE (bridge with VCC)
SBUS_PPM	CSN
LED_STRIP	SCK
TX1	MOSI
RX1 (DSM)	MISO
	IRQ

NOX

See [SilF4ware/STM32F411 NOXE/board_pinout.jpg](http://SilF4ware/STM32F411%20NOXE/board_pinout.jpg)

NOX	NRF24 Mini
3.3V	VCC (bridge with CE)
GND	GND
	CE (bridge with VCC)
NSS A15	CSN
CLK B03	SCK
MOSI B05	MOSI
MISO B04	MISO
	IRQ

From:

<http://sirdomsen.diskstation.me/dokuwiki/> - **Silverware Wiki**

Permanent link:

<http://sirdomsen.diskstation.me/dokuwiki/doku.php?id=silf4ware-wiring>

Last update: **2020/07/07 13:59**

