

My Quad yaws and or banks near full throttle. Is that normal? What to do against that?

My Quad yaws and or banks near full throttle! Is that normal? What to do

The ccw comes with 8 main different motors made by different companies, and sometimes, the ccw and cw motors are a bit different, and can cause this.

<https://sirdomsen.diskstation.me/dokuwiki/>

Silverware Wiki

At full throttle (more than 85%), my quad turn on yaw axis alone

First of all, let's explain the why silverware often has problems. In full throttle, silverware

<https://airdomeendiskstation.me/dokuwiki/doku.php?id=vayang&rev=1480238750>

For corrections with stock settings - but if all your motors and props are perfect, you are

control the quad and have no issues.

```
#define MIX_LOWER_THROTTLE
```

```
#define MIX_THROTTLE_REDUCTION_PERCENT 30
```



Another way would be to change the pid limits to make yaw have higher priority. If file pidle for troubleshooting) and that there is no dust/dirt/hair around the motor shaft!

Quote:

How to solve that? Here is a text, freely copied from [a RCGroups Post by Silverxxx](#)