

## Sbus input

Sbus is an additional input type currently added to the bwhoop code only ( stm32 ). The pin used is one of the programming pins, SWCLK. That means the programming can only be done at powerup, during gyro calibration, or first 2 seconds, whichever is longer

The input pin supports both 3.3v and 5v, which should work with most SBUS receivers available. After signal is detected, the firmware waits for zero throttle for approximately 1 second before accepting the signal. Failsafe is set at 1 second of no signal, internal failsafe of the quad is used, which sets throttle to zero.

To activate sbus input, enable the line " #define RX\_SBUS" in the protocol section of config.h

## Safety

The SBUS input could possible be decoded up incorrectly; it's recommended to test the quad without props first, or in a controlled manner, to make sure the channel order is correct. The correct order is AETR. One may also check the failsafe function at this point, by turning the tx off, while throttle is up.

## Rates

The current scaling is calculated to correspond with taranis settings on 100% limits. Higher limits will also be recognized, but the throttle range will shrink.

From:

<http://sirdomsen.diskstation.me/dokuwiki/> - **Silverware Wiki**

Permanent link:

<http://sirdomsen.diskstation.me/dokuwiki/doku.php?id=sbus&rev=1507096054>

Last update: **2017/10/04 07:47**

