

## Telemetry

For now, all versions supporting Telemetry for Devo plus Devo .dfus in [This RCGroups Post](#)

### Devo 7e update info:

The telemetry is present in deviation firmware in the latest nightlies, currently. That means you may need to flash a recent nightly to make use of telemetry with the bayang protocol, and your flashed quadcopter.

Please back-up the model files, and perhaps other files just in case, when upgrading the transmitter firmware.

To enable telemetry , hit enter when selecting bayang protocol, the same as enabling telemetry for other protocols, such as DSMX

The protocol with telemetry enabled will **only bind to a quad with telemetry capability**. With telemetry off, it will bind to all quads, including factory firmware, and telemetry quads.

### About telemetry data:

The quad sends battery voltage, battery voltage- compensated against throttle , packets received ( reception quality indicator ) , and battery low -led flash signal

Additionally, the tx generates telemetry reception stats.

Telemetry names:

\***Fades\_L** - led battery low flashing= 100 , otherwise 0

\***Loss** - TX's telemetry reception quality indicator in packets per seconds (max 200)

\***Holds** - quad's reception indicator in packets per seconds (max 200 )

\***RxV -Volt1**- real battery voltage

\***Batt -Volt2**- compensated battery voltage

### Alarms:

FadesL > 1 will create an alarm that sounds if the leds flash a low battery code

Batt ≤ 3.40 is ok for low battery as well - using compensated settings from config.h

Rxv ≤ 2.90 - real battery voltage - this would be more like a traditional lvc that sounds on max throttle sometimes

The real voltage goes down a lot, so it may not be very useful. An alarm of 2.8 - 3.0 could be used.

### Additional:

Since the telemetry range is shorter compared to the tx range ( with PA ) , there is no point setting an alarm for quad reception strenght, as the telemetry will probably fail before that level is reached.

From:

<http://sirdomsen.diskstation.me/dokuwiki/> - **Silverware Wiki**

Permanent link:

<http://sirdomsen.diskstation.me/dokuwiki/doku.php?id=telemetry&rev=1480666824>

Last update: **2016/12/02 09:20**

